



CIS PURETEC
A DIVISION OF CIS PHARMA AG

www.cis-puretec.com

CIS Pharma AG
Hauptstrasse 159
CH-4416 Bubendorf
Tel: +41 (0) 61 935 5323
Fax: +41 (0) 61 931 2717
Email: info@cis-pharma.com

Technical Data Sheet

Cuproten SA

Low-foaming cleaning product to remove oxides and dirt from non-ferrous metals

Properties:

Delivered as:	Almost colourless liquid
Odour:	Characteristic
Density (20°C):	1.065 g/ml
pH value (undiluted, 20°C):	1
Mixability with water:	As desired

Application:

Cuproten SA

is used for cold cleaning and gentle deoxidisation of non-ferrous metals.

has a low-foaming formulation.

contains no nitric acid.

with the addition of Aktivator, enables improved and uniform brightening of metal surfaces (add 5 - 10% Aktivator in relation to the quantity of Cuproten used).

can be applied manually when diluted with up to 5 parts of water. The solution is applied with a brush or plastic sponge and is rinsed off thoroughly with water after a short exposure time.

is diluted with 1 - 4 parts of water for use in an immersion bath. The duration of treatment is determined by the degree of contamination. To achieve a better and faster brightening effect, we recommend the addition of Aktivator.

Thorough rinsing with water is required after treatment.

Safety:

The warning printed on the label and the safety advice in the **Safety Data Sheet** must be followed.

Classification: Xi Irritating, R 37/38-41-52/53

Identification:  GHS05 Corrosion